



2004-2006 Pontiac GTO

FOLD UP SWITCH PANEL

Part # 00-11006

INSTALLATION INSTRUCTIONS

Step 1: Remove the console storage compartment.

Step 2: Towards the back of the storage compartment drill a hole in the bottom large enough to loosely fit the switch panel wires through.

Step 3: Now time to start wiring the switch panel. We suggest building a small harness for the switch panel. Using 18-22 gauge wires, make a harness with the wires about 1 foot in length. You have been supplied with flag terminals to crimp to your wires for making the connection. Following the supplied wiring diagram wire your harness to specs. For the jumper wires and connecting to the smaller terminals on the switches we found it easier to solder the connections. Make sure the flag terminals are tweaked to sit up high and all facing the same way towards the driver's side to make sure the wires do not keep the console lid from closing.



Step 4: With your harness complete and plugged onto the switch panel feed the wires through the storage compartment and out the hole in the bottom.

Step 5: Connect the harness wires to the system wiring.

Step 6: Place the console storage compartment back and screw it in.

Step 7: Using the double sided tape supplied with the switch panel peel the covering off both layers and stack them one on top of the other.

Step 8: Center the switch panel on the lid and stick it down. (The placement has to be exactly perfect in order for the console door to close). Make sure when you close it, it does not trigger the switches. It may take a few tries to get it right.



Step 9: Test the system and make sure your wiring is correct.

Step 10: Put the console back together and you are ready to go.

WWW.NITROUSOUTLET.COM

IMPORTANT—All appropriate safety equipment (e.i., gloves, tools) must be used during the installation of this product(s). Nitro Dave's LLC accepts no responsibility for injuries resulting in the installation of any product(s).



2004-2006 Pontiac GTO

FOLD UP SWITCH PANEL

Part # 00-11006

INSTALLATION INSTRUCTIONS

WIRING DIAGRAM

