



# 04-06 GTO Slide In Switch Panel

## SLIDE IN COIN TRAY SWITCH PANEL

Part # 00-11007

### INSTALLATION INSTRUCTIONS

**Step 1:** Remove the console/ashtray storage compartment.

**Step 2:** Towards the back of the ashtray drill a hole large enough to loosely fit the switch panel wires through. 1/2" Should be good.

**Step 3:** Now time to start wiring the switch panel. We suggest building a small harness for the switch panel. Using 18-22 gauge wires, make a harness with the wires about 1 foot in length. You have been supplied with flag terminals to crimp to your wires for making connections. Following the supplied wiring diagram wire your harness to specs. Always solder wire to wire connections.

**Step 4:** With your harness complete and plugged onto the switch panel feed the wires through the storage compartment and out the hole in the bottom.

**Step 5:** Connect the harness wires to the system wiring.

**Step 6:** Place the console storage compartment back and screw it in.

**Step 7:** Test the system and make sure your wiring is correct. With the key in the on position turn on system arm, the solenoids should click. If they don't something is wired wrong. If they do click then turn on the heater and see if it gets warm, then try your purge. Once everything is working correctly move to the next step.

**Step 8:** Once everything is connected and working properly put the console back together and you are ready to go.





# 04-06 GTO Slide In Switch Panel

## SLIDE IN COIN TRAY SWITCH PANEL

Part # 00-11007

### INSTALLATION INSTRUCTIONS

## WIRING DIAGRAM

